MAPLE SYRUP FILLING KIT

A NEW MAPLE SUGARING TREND

Flexible pouch starter kit for maple syrup

1501Ampère street, suite 200 Boucherville (Québec) J4B 5Z5 450 655-6700 1 800 361-0885 bmr.co agrizone.co

The kit includes:

- One automatic filling machine
- · One electric sealing tool
- 1 000 flexible pouches of 250 ml
- 1 000 flexible pouches of 500 ml
- 200 cardboard shipping boxes

Advantages

AUTOMATIC FILLING MACHINE

- Stainless steel on strategic contact zones
- · Easy to clean
- Fill 5 pouches at a time
- Increased productivity up to 500 pouches per hour
- Compact and lightweight

FLEXIBLE POUCHES

- · Lightweight, modern and practical
- With resealable cap
- Delivered flat and empty, to reduce storage and shipping costs
- Stand alone for better visibility
- Maximum syrup conservation before and after opening
- · Less waste and spills
- Shockproof



Click on the link above to see the video presentation of the product



500 POUCHES PER HOUR

> 5 LINES TO FILL

REDUCTION OF FEES

* Possibility of ordering each product individually.

 250 ml
 500 ml
 Shipping pouches
 Electric sealing tool
 Filling machine

 073-7140
 073-7159
 073-7122
 073-7380
 073-7131

Manual of use

The machine can be operated in manual or automatic mode.

MANUAL MODE

The manual mode is simple. The machine can be operated by a single person. This mode allows filling according to the rhythm of the operator. After starting the machine, prepare the syrup at the correct storage temperature. The operator must calibrate the machine to obtain the standard filling time for the desired volume. The filling is done in an On - Off way by pressing on a pedal or by button on the control panel.

AUTOMATIC MODE

The automatic mode is selected on the screen board. The operator calibrates the machine to obtain the standard filling time for the desired volume. By choosing from the control panel menu the waiting time between each filling the filling operation is done automatically without the operator activating the pedal or the button on the control panel.

Maintenance and cleaning

- · Should be done before and after each use
- Circulate hot water through the system for a few minutes
- Do not use soap or other cleaning products in the machine



